ProStar[™] PIPER

High-Accuracy Pipe-Cutting Machine





Three-Ton, High-Accuracy Pipe Cutter

PRECISE 3D CUTTING & BEVELING

ProStar's Piper 3T is a well-standardized pipe-cutting machine that makes use of a three-jaw chuck to clamp and rotate the pipe during cutting. Pipe diameters up to 24 in. (610 mm) can be processed in a wide range of lengths and profile shapes. The ability to perform high-accuracy cutting using plasma and/or oxy-fuel, and a variety of standard features, qualifies the PRSPIPER3T as a good fit for almost shop and budget.

Standard Features

- Plasma & oxy-fuel systems
- Main drive 3-jaw chuck
- Pipe trolleys
- Cutting trolley
- Deltatau[®] motion control
- Panasonic® electronics and motors
- Wago[®] remote bus IO
- Airflow cooling
- Industrial PC with SSD drive
- Touch screen operator controls

STANDARD CONFIGURATION


PART NO.	MIN OUTER DIA.		MAX OUTER DIA.		MAX PIPE WEIGHT		MAX PIPE LENGTH	
PRSPIPER3T	2 in.	48 mm	24 in.	610 mm	3.31 t	3 t	20 ft 40 ft.*	6 m - 12 m*

^{*40} ft. (12 m) pipe length optional

Pipe & Vessel Cutting Machines

Ask Praxair to help your business compete more effectively in today's worldwide markets.







THREE-JAW CHUCK

Self-centering chuck provides high-accuracy cutting. The securely clamped pipe will not slip or creep during rotation.



PLASMA AND/OR OXY-FUEL

A compact pantograph arm enables the PRSPIPER3T to perform 3D cutting, using both plasma and/or oxy-fuel processes.



PIPE SUPPORTS

Adjustable pipe supports level the pipe at the cut location. For permanent horizontal support, add an available "rollerball" gutter.

MACHINE TECHNICAL DATA	POSITIONING	REPEATABILITY
MAIN DRIVE ROTATION Ø 600 MM	0.25°	0.13°
TORCH TILTING (PITCH AND ROLL)	0.50°	0.25°
MAIN DRIVE UP/DOWN MOVEMENT	Hydraulic (manual)	Hydraulic (manual)
CUTTING TROLLEY LONGITUDINAL MOVEMENT	0.020 in.	0.0010 in.
TORCH/MATERIAL DISTANCE	0.0040 in.	0.020 in.

^{*}Machine accuracy does not concern the accuracy of the cutting process.

Specifications subject to change without notice. Consult your Praxair representative when ordering.